

# Lohff & Pfeiffer

More info at: [www.woodwindexpert.com](http://www.woodwindexpert.com) [info@woodwindexpert.com](mailto:info@woodwindexpert.com) +45 3535 8643

Martin					
Brand	Instrument	Model	Year	Start No.	Ending No
Martin	A & Bb-clarinet		1953		183125
Martin	A & Bb-clarinet		1954	183126	187614
Martin	A & Bb-clarinet		1955	187615	193747
Martin	A & Bb-clarinet		1956	193748	196213
Martin	A & Bb-clarinet		1957	196214	201917
Martin	A & Bb-clarinet		1958	201918	203809
Martin	A & Bb-clarinet		1959	203810	205377
Martin	A & Bb-clarinet		1960	205378	209089
Martin	A & Bb-clarinet		1961	209090	211675
Martin	A & Bb-clarinet		1962	211676	213999
Martin	A & Bb-clarinet		1963	214000	218855
Martin	Saxophone		1919	17221	19481
Martin	Saxophone		1920	19482	23780
Martin	Saxophone		1921	23781	29941
Martin	Saxophone		1922	29942	34837
Martin	Saxophone		1923	34838	40643
Martin	Saxophone		1924	40644	48488
Martin	Saxophone		1925	48489	67851
Martin	Saxophone		1926	67852	79253
Martin	Saxophone		1927	79254	86686
Martin	Saxophone		1928	86687	92535
Martin	Saxophone		1929	92536	98323
Martin	Saxophone		1930	98324	101621
Martin	Saxophone		1931	101622	105098
Martin	Saxophone		1932	105099	106545
Martin	Saxophone		1933	106546	108300
Martin	Saxophone		1934	108301	111252
Martin	Saxophone		1935	111253	116550
Martin	Saxophone		1936	116551	118037
Martin	Saxophone		1937	118038	126997
Martin	Saxophone		1938	126998	132069
Martin	Saxophone		1939	132070	136039
Martin	Saxophone		1940	136040	140198
Martin	Saxophone		1941	140199	144454
Martin	Saxophone		1942	144455	145321

Or at Lohff & Pfeiffer USA LLC: [www.lpwindusa.com](http://www.lpwindusa.com) [info@lpwindusa.com](mailto:info@lpwindusa.com) +1 812  
929 5556

# Lohff & Pfeiffer

More info at: [www.woodwindexpert.com](http://www.woodwindexpert.com) [info@woodwindexpert.com](mailto:info@woodwindexpert.com) +45 3535 8643

Martin	Saxophone		1943	145322	145322
Martin	Saxophone		1944	145323	145351
Martin	Saxophone		1945	145352	154298
Martin	Saxophone		1946	154299	161519
Martin	Saxophone		1947	161520	165325
Martin	Saxophone		1948	165326	170395
Martin	Saxophone		1949	170396	172214
Martin	Saxophone		1950	172215	175139
Martin	Saxophone		1951	175140	179316
Martin	Saxophone		1952	179317	183124
Martin	Saxophone		1953	183125	187614
Martin	Saxophone		1954	187615	193746
Martin	Saxophone		1955	193747	196212
Martin	Saxophone		1956	196213	201917
Martin	Saxophone		1957	201918	203808
Martin	Saxophone		1958	203809	205376
Martin	Saxophone		1959	205377	209088
Martin	Saxophone		1960	209089	211674
Martin	Saxophone		1961	211675	213998
Martin	Saxophone		1962	213999	218854

[www.woodwindexpert.com](http://www.woodwindexpert.com)

Or at Lohff & Pfeiffer USA LLC: [www.lpwindsusa.com](http://www.lpwindsusa.com) [info@lpwindsusa.com](mailto:info@lpwindsusa.com) +1 812  
929 5556